① Reference the Glass Panel Specification document to confirm drill hole locations.
② Measure and cut the provided rubber insert to match thickness of door panel.
③ Install rubber insert inside of hole.
④ Install screws with included wrench, match screw length with panel thickness.
⑤ Install Ebba as shown below.

Door Panel
Thickness