

## WOOD DOOR PANELS

- ① Install threaded studs fully into each knob.
- ② Determine if the knobs can be installed inline or offset based on door thickness and the length of studs in each knob.
- ③ Prepare the door by drilling pilot holes at desired locations.
- ④ Install knob assembly onto door by hand until firmly snug. Tools can damage surface!
- ⑤ Repeat for other side.

