

WALL MOUNT

- (!) Mounting Point hardware must be secured to structurally solid material.
- ① Installation onto drywall: Core out 1/2" hole for Drywall Insert. For installation onto structurally solid material, skip to Step 3.
 - ② Use provided Drywall Shims to ensure that Drywall Insert is installed flush with finished surface.
 - ③ Predrill and install Mounting Point assembly as shown, ensuring that Cone-head Plate is structurally supported.
 - ④ Softly tighten Mounting Screws to 48 inch-lb. (4 ft-lb.) or less to avoid crushing substrate material.
 - ⑤ With Towel Bar firmly pressed up against Surface Plate, softly tighten Set Screws to 30 inch-lb. (2.5 ft-lb.).

