

INSTALLATION INSTRUCTIONS - ADJUSTABLE GLASS DOOR GUIDE

- ⚠ Door panel may not yet be fully constrained in its travel.
- ① Confirm that the gap between floor and door panel is sufficient for the door guide in the overlap area. Make system height adjustments if needed.
- ℹ Note that some Krownlab systems allow for door height adjustment after door guide install. Refer to the main installation instruction document.
- ② With the door in the desired closed position, mark the leading edge of your door panel on the floor.
- ③ With the door in the desired open position, mark the trailing edge of your door panel on the floor.
- ⚠ Minimum width of overlap area is 2". Adjust desired door travel if needed.
- ④ Temporarily move the door panel beyond the fully open position, revealing the overlap area for door guide install.
- ⚠* If installation does not allow the door panel to be moved beyond the overlap area, carefully tilt the door panel out of the way and first install door guide mount only. Then with door panel in position, slide the door guide onto mount and secure. **Ensure that door guide floor location provides access to both guide mount set screws after installation.**
- ⑤ Install the door guide in the overlap area (4) as shown.
- ⚠ Ensure that the door panel hangs plumb when installed.
- ⚠ Provided fasteners and expansion anchors are not suitable for all types of floors. Caulking or sealing of floor penetrations may be required by contractor.
- ⑥ Adjust the door guide to the thickness of the door panel using the provided 2mm Allen wrench. Ensure that the door panel remains plumb.

