


INSTALL COMPACT GLASS DOOR GUIDE

- ① With the door in the desired closed position, mark the leading edge of your door panel.
 - ② With the door in the desired open position, mark the trailing edge of your door panel.
 - ③ Temporarily move the door panel beyond the fully open position, revealing the overlap area.
 - ④ Install the glass Door Guide in the overlap area (3).
- ⚠ Position it at the appropriate distance from the wall so that the door panel hangs plumb.

 Installation of a Door Guide is mandatory. Door panel has to be engaged by the Door Guide along its entire travel. Not following the above instructions can cause a hazardous condition.

