

MIRROR – SINGLE SIDED

- (!) Reference the Kor Product Specifications document to confirm glass hole specifications.
- (!) All gasket and bushing components must be installed as shown.
- (!) If required, trim length of Rubber Bushing to mirror thickness.
- ① Drill ½" hole in desired location respecting minimum distances from mirror edges using appropriate drill.
- ② Install all components as shown without tightening fasteners all the way.
- ③ Ensure the rubber side of the Gasket-backed Washer is against the mirror.
- ④ Ensure that all parts are aligned properly.
- ⑤ Softly tighten Mounting Screw to 48 inch-lb. (4 ft-lb.).
- (!) Do not counter-twist or rotate Kor Knob.

