

GLASS PANELS

- (!) Reference the Inger Product Specifications document to confirm hole specifications.
- ① Install all components as shown without tightening fasteners all the way.
- ② Ensure the rubber side of the Knob washer is against the glass.
- (!) The rubber and plastic components must be used with glass panels.
- ③ Ensure all parts are lining up properly.
- ④ Tighten large mounting screw to 84 inch-lbs (7 ft-lbs).
- ⑤ Softly tighten Kor Knob until firmly snug.

