

INSTALL 2-PART WOOD DOOR GUIDE

- ① With the door in the desired closed position, mark the leading edge of your door panel.
- ② With the door in the desired open position, mark the trailing edge of your door panel.
- ③ Temporarily move the door panel beyond the fully open position, revealing the overlap area.
- ④ Install the Door Guide in the overlap area (3) as shown. Size the Door Guide to fit your door panel thickness.
- ⚠ Position the Door Guide at the appropriate distance from the wall so that the door panel hangs plumb.
- ⑤ You can now install your door pulls and other door hardware.

⚠ Installation of a Door Guide is mandatory. Door panel has to be engaged by the Door Guide along its entire travel. Not following the above instructions can cause a hazardous condition.

