

INSTALLATION INSTRUCTIONS - FLOOR GUIDE CHANNEL

The floor guide channel is designed for installations where the door panel travel distance exceeds the door panel width. The floor guide is installed into the bottom of the door panel rather than into the floor. Examples include Bypass Stacked door configurations, and marker board applications.

- ① With the door panel in plumbed position, mark the centerline to determine the lateral position of the floor guide channel.
- ② Define the length and floor location of the floor guide channel by positioning the door panel in the desired far left and far right positions. The distance between the floor guide post in these two positions equals **door panel travel** as shown.
- ❗ We recommend adding 2" at both ends of the door panel travel to provide door panel travel adjustment and a margin for error.
- ③ Using the above defined length and floor location, route channel in floor to width and depth as shown.
- ④ Square ends of routed channel to fit floor guide channel.
- ⑤ Cut floor guide channel to match length of routed channel in floor.
- ⑥ Drill holes in channel as shown. Locate holes 2" from each end, and with a maximum of 12" spacing in between.
- ⑦ Install floor guide channel using provided fasteners.
- ⑧ Remove door panel from track and install floor guide on door panel centerline as shown. Use provided shims as needed.
- ⑨ Carefully rehang door panel positioning floor guide post into floor guide channel.

Return to main installation document.

