

GLASS DOOR PANELS

- (!) Reference the Kor Product Specifications document to confirm glass panel hole specifications.
- (!) All gasket and bushing components must be installed as shown.
- ① Reference the relevant configuration below.
- ② Install all components as shown without tightening fasteners all the way.
- ③ Ensure that all parts are aligned properly.
- ④ Tighten large Mounting Screws to 84 inch-lb. (7 ft-lb.).
- ⑤ Softly tighten small Set Screws to 30 inch-lb. (2.5 ft-lb.).

