

INSTALLATION INSTRUCTIONS - ADJUSTABLE GLASS DOOR GUIDE

- ① With the door in the desired closed position, mark the leading edge of your door panel on the floor.
- ② With the door in the desired open position, mark the trailing edge of your door panel on the floor.
- ③ Temporarily move the door panel beyond the fully open position, revealing the overlap area.
- * If the installation does not allow the door panel to be moved beyond the overlap area, first install Door Guide Plate by fitting the door panel away from the wall. Then install the Door Guide using provided 2mm Allen wrench.
- ④ Install the Door Guide in the overlap area (3) as shown below.
- ! Provided fasteners and expansion anchors are not suitable for all types of floors.
- ! Position the Door Guide in the appropriate position so that the door panel hangs plumb when installed.
- ⑤ Adjust the Door Guide to the thickness of the door panel using the provided 2mm Allen wrench. Ensure that the door panel remains plumb.

! Installation of a Door Guide is mandatory. Door panel has to be engaged by the Door Guide along its entire travel. Not following these instructions can cause a hazardous condition.

