

OPTIONAL STEP - PERPENDICULAR TRACK MOUNT (GW)

- ① Install the end cap that is packaged with the perpendicular track mount on the corresponding end of the track. If the track came pre-installed with end caps, replace the appropriate end cap.
- ② Adjust the height of the perpendicular glass wall (A) until the holes are vertically centered on the centerline of the track.
- ③ Determine the horizontal position of the perpendicular glass wall using the table below and adjust it horizontally as needed. The panel distance was determined in the previous step in the main installation instructions, and also should have been determined when the glass was ordered.

Panel Distance	Horizontal Position (4)
7/8" and 1"	29/32"
1-3/8" and 1-1/2"	1-13/32"
1-5/8" and 1-3/4"	1-21/32"

- ④ Install the perpendicular track mount with the supplied 1" long screws as shown. Torque screws to 110 in-lbs (9.5ft-lbs).
- ⑤ Install track base into tightened perpendicular track mount and loosely attach one track mount at other end of track. Track cover installs later.
- ⑥ Slide the hex nut over the hole nearest the opening of the socket and install provided button head screw into the hex nut.
- ⑦ Install the provided button head screw into the remaining threaded hole on the bottom of the socket. This screw installs beyond the end of the track to limit motion in the event the track shifts.
- ⑧ Torque both button head screws to 110 in-lbs (9.5 ft-lbs).

Return to main installation instructions.

