
KOR TOWEL BAR - INSTALLATION INSTRUCTIONS

₩ KROWNLAB

GLASS MOUNT: SLIDING GLASS DOOR

- (!) Reference the Kor Product Specifications document to confirm glass hole specifications.
- (!) All gasket and bushing components must be installed as shown.
- (1) Install Threaded Insert flush with Stand-off.
- (2) Install All-thread Fastener fully into Kor Knob.
- (3) Install all remaining components as shown without tightening fasteners all the way, ensuring that the gasket side of the Gasket-Backed Washer is against the glass.



5 Tighten Mounting Screw to 84 inch-lb. (7 ft-lb.).

6 Softly tighten Kor Knob until firmly snug.

